


Silento-31

Vacuum Head SwitchBox TOP view part#1E77011 & Handle assy Part # 1E77015



- 1. 6E13400 Tapping Screw
- 2. 6K02006 Lock Washer
- 3. 6K02000 Flat washer
- 4. 1E60524 Acoustic foam #5
- 5. 1E60530 Disc gasket
- 6. 1E53500 Handle
- 7. 7D55001 RapStrap
- 8. 1E05410 Decal
- 9. 1E77016 Handle spinning
- 11. 6A14906 Screw
- 14. 6D02204 Nut, Anchore type
- 16. 1E77012 Switch box
- 17. 1E77031 Stand off
- 18. 6A19309 Mach Screw
- 20. 1E05408 Decal "Normal-Silent"
- 22. 7D54110 Switch 2 speed
- 24. 7D54000 Power outlet
- 26. 6A05300 Mach. Screw
- 28. 7D10100 "Full bag" Indicator
- 29. 1E05406 Decal "Service filter"
- 32. 6D01801 Nutsert
- 34. 1E05411 Date plate (not shown)
- 35. 1E57912 Plug (not shown)

